



Fitting Instructions

TOWBAR RN73Q
for Renault Megane Sports Tourer 2003-
and Renault Megane Sports Saloon 2003-

MATERIALS

A	1	Towbar Mainframe
C	1	Right Sidearm
D	1	Left Sidearm
E	2	M12 x 35 x 1.75 Bolts, Nuts, Lock Washers and Flat Washers (25mm O.D)
F	2	M12 x 45 x 1.75 Bolts, Lock Washers and Large Flat Washers (40mm O.D)
G	2	M10 x 35 x 1.5 Bolts, Lock Washers and Large Flat Washers (40mm O.D)
ZEP2	1	Electrical Plate
ZQ	1	Detachable Swan Neck (ZQ2008)

FITTING

1. Remove and disconnect rear light clusters (remove 3 nuts and gently pull cluster rearward).
2. Remove bumper (For the **Sports Saloon**: remove 6 popping fixings along top edge of bumper, 2 self tapping screws on rear side of each wheel arch, 6 screws on underside of bumper) (For the **Sports Tourer**: remove 4 screws around the light cluster, 3 self tapping screws on rear side of each wheel arch (1 hidden behind overlaying mud flap), 7 screws on underside of bumper) gently pull bumper tips outwards and upwards before gently pulling bumper rearward.
3. Remove bumper reinforcement beam (hand to customer), the left hand side plastic bumper stiffener, rubber chassis rail blanking plates, spare wheel and jack/polystyrene assembly.
4. Insert Sidearms (C and D) into chassis rails as shown, loosely attach using Bolts (G). **Note:** Holes in chassis rails for Bolts (F and G) are covered with tape.
5. Loosely attach Towbar Mainframe (A) to Sidearms (C and D) using Bolts (E and F). **Note:** On left side, access for socket/extension bar for Bolts (F) is obtained by lifting up boot trim (remove 4 torq screws hidden under caps), moving foam insulation and removing blanking plug on outer skin of rear wing, or by removing the air vent on the side of the chassis panel. **Tighten All Bolts.**
6. Seal ends of chassis rails with tape and / or replacing rubber chassis rail blanking plates (after cutting relevant slots for Sidearms (C and D), sealant or expanding foam to prevent ingress of water. Bend bumper tags down while reattaching bumper. **Note: Protect outer face of bumper from Towbar Mainframe (A).**
7. Replace trim, bumper, spare wheel, jack/polystyrene assembly, and rear light clusters.
8. Attach ZQ (Detachable Swan Neck (ZQ2008)) and Electrical Plate (ZEP2) as per separate instruction. **Note:**

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

