

## Toyota Corolla LB '97

### Réf. 1023

#### Fitting instructions

1. Dismantle bumper and towing rings at end of vehicle.  
Demount and remove the fixation tube on the coach work.
2. Install tow bar with points A and A' against the back of the coach work on the deliberated holes (picture 2). Points B and C push in the chassis via the deliberated holes and fit with the existing drillings (picture 3). At points A' install tubes between coach work and tow bar. Afterwards insert bolts with washers (picture 4-5). At points B install the mounting pieces -f on the bottom. Also install washers at points C at the exterior side of the chassis. Insert bolts and fasten with bolts.
3. Reinstall bumper but firstly make an incision (picture 6).
4. Mount (\*) and fasten with bolts.

#### Composition

Tow bar reference 1023

1 tow bar	
1 ball T43/K or T35 or piece 50T	(*)
4 bolts M12-40 + washers	(*)
2 bolts M8-35 + washers	(A)
2 bolts M8-40 + washers	(A')
4 bolts M10-30 + washers	(B)
2 bolts M10-40 + nuts and washers	(C)
2 washers diam. 40x12x4mm	(C)
4 washers diam. 25x8x2mm	(A-A')
2 tubes diam. 22-10-10mm	(A')
2 mounting pieces -f	(B)
1 security shackle	