

VW6057

Batch 000000

Volkswagen Golf & Golf Plus

Type Approval Number e11 00-7754

COMPONENTS

ITEM	QTY	DESCRIPTION
A	1	Towbar
B	1	Detachable Towbar Neck Kit – ZCA6011 > Detachable Towbar Neck & Housing > Weather Plug > Storage Bag > Operation Manual > Swan Neck Ball Cap (ZM1406)
C	1	Side Arm (LH)
D	1	Side Arm (RH)
EP	1	Electrical Mounting Bracket (ZM1390)

BOLT PACK

ITEM	QTY	DESCRIPTION
F	4	M12 x 25 Bolts & Washers
G	4	M10 x 45 Bolts (10.9 Grade) & Washers
H	2	M10 x 35 Bolts (10.9 Grade) & Washers
I	4	M10 H/D Washers – 30mm O/D x 5mm Thick
J	3	M12 Washers – 23mm O/D x 1.6mm Thick

FITTING PROCEDURE

- ⇒ **Important Information:** For use with Volkswagen original equipment bumper spoiler with cut out and towbar panel. Please contact Volkswagen dealer with vehicle description and vehicle identification number (VIN) to source the correct parts.
- ⇒ Remove rear light clusters (2 nuts (1 on Golf VI) per light behind boot trim). Remove bumper (2 torx screws beneath each light cluster (Clips on Golf VI), 4/5 torx screws on lower edge, torx screws around each wheel arch (Golf Plus – pull down plastic slider), 1 torx screw holding wheel arch liner to bumper, disconnect number plate light).
- ⇒ Remove the impact beam and retain if the towbar is removed. Replace bolts into rear panel to prevent water ingress, ensuring they do not damage the trim panel inside the boot.
- ⇒ Locate the towbar mounting points in the outside of the chassis rail (Often covered in adhesive tape and underseal).
- ⇒ Insert side arms (C) & (D) into vehicle chassis and loosely attach at the forward points using bolts (H) with heavy duty washers (I) under the bolt heads.
- ⇒ Insert towbar (A) into ends of chassis and loosely attach to side arms (C) & (D) / chassis at rear mounting points using bolts (G) with heavy duty washers (I) under the bolt heads. Loosely attach side arms (C) & (D) to towbar (A) using remaining bolts (G). Tighten all bolts (**Note: Bolts (G) & (H) are 10.9 grade and require tightening to 64Nm**).
- ⇒ Attach detachable towbar neck housing (B) & electrical mounting bracket (EP) to towbar (A) using bolts (F) as shown. **Note: Where there is no electrical mounting bracket (EP), use additional flat washers (J) under the bolt heads. The electrical mounting bracket carries type approval information required by law and must always be fitted as shown.**
- ⇒ **For 12N or 13 Pin Electrical Socket Fitment:** Mount electrical mounting bracket (EP) to the left of the towbar as illustrated. The electrical mounting bracket needs to be angled with the lower edge towards the vehicle body. On Golf V models, rotate the socket by 90 degrees as illustrated.
- ⇒ **For 12S Electrical Socket Fitment:** For 12S Socket Additions it will be necessary to use additional Electrical Mounting Bracket ZM1391 (Purchased Separately). This is mounted to the right of the towbar as illustrated by the ghost image. Ensure the socket does not impede on the operation of the detachable neck mechanism.
- ⇒ Tighten neck bolts. Note: It is suggested that the bolt securing the electrical mounting bracket is left loose until after bumper re-fitment to allow for correct alignment and operation.
- ⇒ Remove black spoiler from lower edge of rear bumper. Replace with Volkswagen parts department supplied replacement spoiler with cut out and towbar panel.
- ⇒ Refit bumper and light clusters.
- ⇒ **NOTE:** Please refer to Operation Manual for Use and Maintenance of the Detachable Neck System.

TIGHTEN ALL BOLTS


TORQUE SETTINGS ISO Coarse Pitch M8=29Nm, M10=58Nm, M12=102Nm, M16=252Nm
ISO Fine Pitch M8=31Nm, M10=61Nm, M12=111Nm

THE VEHICLE MANUFACTURER'S SPECIFICATION FOR THE TRAILER WEIGHT AND NOSE LOAD LIMITS MUST BE OBSERVED.

VW6057
Batch 000000

Volkswagen Golf & Golf Plus
Type Approval Number e11 00-7754


FITTING DIAGRAM



ELECTRICAL SOCKET ORIENTATION



GOLF VI



GOLF V & PLUS

IMPORTANT PRODUCT INFORMATION & GUARANTEE

(TO BE RETAINED WITH THE VEHICLE AND PASSED TO SUBSEQUENT OWNERS)

Thank you for purchasing a PCT Automotive product. Please read the following information carefully before fitting or using your PCT Automotive product.

GUARANTEE

We shall free of charge either repair or at our option replace defective goods where the defects appear

- i. if the goods are a towbar manufactured by us, during the economic lifetime of the vehicle it was first fitted to
- ii. in the case of all other products manufactured by us, within 3 years following the date of your order

PROVIDED THAT (in each case) such defects shall be found to our reasonable satisfaction to have arisen substantially from our faulty design, workmanship or materials and have not arisen by reason of a failure to follow our instructions (whether written or oral), any modification, misuse, neglect or interference with the installation, any damage or abuse to the goods or vehicle by impact or vandalism or by a failure to carry out reasonable inspection, maintenance and/or adjustment.

At all times, the above guarantee is subject to our standard terms and conditions of sale a copy of which is available upon request from our offices.

TOWING LIMITS

Our towbars have been designed for towing up to the vehicle manufacturer's maximum recommended trailer weight and nose load limits for your model. Towing with gross weights above that recommended at any time will invalidate the guarantee and cancel any liability for damage. Towing a twin axle trailer, towing over rough ground or using a bicycle/motorcycle carrier, etc, exerts extreme loads on to a towbar and extra care should be taken in these situations not to exceed the vehicle manufacturer's maximum recommended limits.

PRODUCT IDENTIFICATION MARK

Your product carries a product identification mark. This mark carries important product and batch code information and if the product is type approved it also carries the type approval details which are required by law. Under no circumstances should this mark be defaced, removed or damaged.

INSTALLATION, INSPECTION, MAINTENANCE AND ADJUSTMENT

GENERAL INSTALLATION

- ⇒ Products should only be fitted by competent persons.
- ⇒ Read the product fitting instructions carefully and check all components are included in the fitting kit before commencing installation.
- ⇒ Check vehicle for corrosion and/or accident damage. Towbars should not be fitted to any vehicle suffering from corrosion or accident damage or which is not in a roadworthy condition.
- ⇒ Clean off all road dirt, underseal and sound deadening mastic where parts are to fit to ensure correct seating of all components.
- ⇒ Bumper cut information is given as a guide only. Variations in models may occur therefore the fitter should always check that the bumper cut is necessary and of the correct size and shape before commencing with the cut.
- ⇒ All drilling swarf should be removed from the vehicle and all holes drilled in the vehicle should be treated with an appropriate rust inhibitor.
- ⇒ Do not fully tighten bolts before towbar is completely fitted unless instructed to do so in the fitting instruction, this will allow some variances to be overcome before final tightening of bolts.

PAINT & CORROSION

Towbars manufactured by PCT Automotive undergo a phosphate chemical pre-treatment prior to an epoxy/polyester powder coat finish being applied. For long lasting good looks and in order to prevent corrosion the towbar should be regularly inspected for paint damage and wherever necessary re-painted in an appropriate finishing paint or underseal. The vehicle should also be regularly checked for any corrosion that could affect the towbar installation. Towbars should not be used on any vehicle suffering from corrosion that could affect the towbar installation.

BOLTS

All towbar fixing bolts should be checked initially after the first 300 towing miles and then every 3,000 towing miles or to coincide with the vehicle manufacturer's recommended service intervals, whichever is the sooner, and should be tightened using an appropriate torque wrench to the settings specified in the towbar fitting instruction.

ELECTRICAL INSTALLATION, TEST/COMMISSIONING AND MAINTENANCE

Failure to comply with the following instructions may cause damage to the towing vehicle's wiring loom and/or towing electrics installation.

Where displacement tap connectors e.g. Scotchlocks, are the preferred method of connection, always use the correct colour coded tap connector for the size of cable to which it is to be connected. PCT Automotive's manufactured relays with integral cables should be connected using red tap connectors (0.5mm² to 1mm², conductor cross sectional area).

After installation of the 12N/12S sockets, prior to testing, a water displacement agent e.g. WD40 should be applied into the rear connection void through the water drain hole at the bottom of the sockets and also into the front pins under the socket flap. This socket maintenance should be carried out at least twice a year in the spring and autumn.

The towing electrics test procedure must be undertaken with the engine running. If any of the towing relays fail to function correctly, with the engine running and no other vehicle electrical systems turned on, check that the voltage across the vehicle's battery is between 13V and 14V approx, if this voltage is not correct, check the condition of the vehicle's battery/alternator.

Always ensure that the trailer/caravan/lighting board's own electrical systems are installed and functioning correctly before coupling to the vehicle's 12N/12S sockets.

Every six months (spring and autumn recommended) the battery and alternator of the vehicle should be checked to determine correct electrical functioning. All connections of the electrical installation including the earth should be checked for mechanical soundness and electrical quality. Plugs, sockets, relays and fixings should be checked for water ingress, mechanical soundness, electrical quality and general wear and tear.

Please complete the following information to validate the guarantee and for future reference.

VEHICLE OWNER NAME & ADDRESS:

VEHICLE MAKE & MODEL:

VEHICLE REGISTRATION NUMBER:

FITTER NAME & ADDRESS:

DATE TOWBAR FITTED:

If you have any comments or suggestions about the PCT Automotive product fitted to your vehicle, please address them to PCT Automotive, Holbrook Industrial Estate, Sheffield S20 3GH or email techsupport@pctautomotive.com
Your comments will help us in our aim to continually upgrade our products to meet the high standards expected by our customers.