

MR5099

Mercedes-Benz GLA (X156) (From 2014)

Type Approval Number E11*55R03/00*11667*01

COMPONENTS

ITEM	QTY	DESCRIPTION
A	1	Crossbar
B	1	Swan Neck: ZC1610
Z	2	Handed ZC1599
C	1	Side Arms
EP	1	Retractable Electrical Mounting Bkt ZM2206

BOLT PACK

ITEM	QTY	DESCRIPTION
F	8	M12 x 35 Bolts, Nuts & Washers
G	2	M12 x 35 Bolts, Nuts & Washers
H	4	M12 x 35 Bolts & Washers
I	10	M12 H/D Washers – 30mm O/D x 5mm Thick
J	12	M12 Washers – 23mm O/D x 1.6mm Thick
EP1	1	M12 x 25 Bolt & Nyloc Nut
EP2	1	M12 Nylon Washer
EP3	2	M12 Washers - 23mm O/D
X	2	M12 x 70 Bolts & Nyloc Nuts (10.9 Grade)
Y	4	M12 X 35 Bolts, Nuts & SP Washers (10.9 Grade)

FITTING PROCEDURE

Remove rear light clusters (1 retaining nut & harness on the rear of each accessed through hole in trim inside boot). Remove bumper (4x10mm bolts and 4x push in plugs on the lower edge, 1x push in plug on each wheelarch, 1x 10mm bolt at each bumper tip. From inside boot, remove rear trim panel and remove the 10mm nuts from inside the rear box section (Hidden behind sealing tape) - **Note:** Long socket required! Carefully release the wheelarch surrounds (Clipped to bumper & glued against the vehicle body!). Pull bumper tips outward to release from clips along bumper-body edge before pulling rearward. Disconnect plug for reversing sensors if fitted.

Lower exhaust and temporarily remove the heat shield (6x8mm fixings). Remove and discard the bumper impact beam (8x16mm nuts forward of the rear panel) (Hand to vehicle operator for retention if towbar is removed).

Locate the mounting hole in the outside wall of each chassis rail and remove the rubber grommet. Insert side arms (C) into open ends of vehicle chassis and loosely attach using bolts (H) with flat washers (I) under the bolt heads. Loosely attach towbar (A) to the existing holes on the vehicle's rear panel using bolts (F) with flat washers (J) under the bolt heads and heavy-duty washers (I) forward of the panel.

Attach side arms (C) to towbar (A) using bolts (G) & (H) as illustrated. Use M12 washers (J) under the bolt heads.

Fully tighten all bolts ensuring components remain square and level. **Note: To prevent water ingress, it is imperative that sealant is used around the perimeter of the towbar where interfacing with the rear panel, and around the side arm entry points.**

Replace heat shield (If necessary, bend/trim section where it interfaces with the secondary coupling position. Raise exhaust.

Loosely attach Swan neck **B** to brackets **Z** using bolts **X**. Attach brackets **Z** to crossbar **A** and electrical bracket **EP** using bolts **Y**. Tighten bolts


Make a cut in the bumper as illustrated. Refit bumper and light clusters.

TIGHTEN ALL BOLTS USING THE FOLLOWING TORQUE SETTINGS


ISO Coarse Pitch: M8=25Nm, M10=51Nm, M12=92Nm, M14=140Nm, M16=215Nm ISO Fine Pitch: M8=28Nm, M10=54Nm, M12=96Nm, M14=150Nm

THE VEHICLE MANUFACTURER'S SPECIFICATION FOR THE TRAILER WEIGHT AND NOSE LOAD LIMITS MUST BE OBSERVED.

FITTING DIAGRAM



BUMPER CUT DETAIL



INSIDE VIEW OF BUMPER

IMPORTANT PRODUCT INFORMATION & GUARANTEE

(TO BE RETAINED WITH THE VEHICLE AND PASSED TO SUBSEQUENT OWNERS)

Thank you for purchasing a PCT Automotive product. Please read the following information carefully before fitting or using your PCT Automotive product.

GUARANTEE

We shall free of charge either repair or at our option replace defective goods where the defects appear

- i. if the goods are a towbar manufactured by us, during the economic lifetime of the vehicle it was first fitted to
- ii. in the case of all other products manufactured by us, within 3 years following the date of your order
- iii. in the case of a product not manufactured by us, we will pass on any warranty offered to us by the manufacturer of that product or component

PROVIDED THAT (in each case) such defects shall be found to our reasonable satisfaction to have arisen substantially from our faulty design, workmanship or materials and have not arisen by reason of a failure to follow our instructions (whether written or oral), any modification, misuse, neglect or interference with the installation, any damage or abuse to the goods or vehicle by impact or vandalism or by a failure to carry out reasonable inspection, maintenance and/or adjustment. At all times, the above guarantee is subject to our standard terms and conditions of sale a copy of which is available upon request from our offices.

TOWING LIMITS

Our towbars have been designed for towing up to the vehicle manufacturer's maximum recommended trailer weight and nose load limits for your model. Towing with gross weights above that recommended at any time will invalidate the guarantee and cancel any liability for damage. Towing a twin axle trailer, towing over rough ground or using a bicycle/motorcycle carrier, etc, exerts extreme loads on to a towbar and extra care should be taken in these situations not to exceed the vehicle manufacturer's maximum recommended limits.

PRODUCT IDENTIFICATION MARK

Your product carries a product identification mark. This mark carries important product and batch code information and if the product is type approved it also carries the type approval details which are required by law. Under no circumstances should this mark be defaced, removed or damaged.

INSTALLATION, INSPECTION, MAINTENANCE AND ADJUSTMENT

GENERAL INSTALLATION

- ⇒ All products should only be fitted by competent persons. Electrical products must only be fitted by an experienced auto-electrician.
- ⇒ Read the product fitting instructions carefully and check all components are included in the fitting kit before commencing installation.
- ⇒ Check vehicle for corrosion and/or accident damage. Towbars should not be fitted to any vehicle suffering from corrosion or accident damage or which is not in a roadworthy condition.
- ⇒ Clean off all road dirt, underseal and sound deadening mastic where parts are to fit to ensure correct seating of all components.
- ⇒ Bumper cut information is given as a guide only. Variations in models may occur therefore the fitter should always check that the bumper cut is necessary and of the correct size and shape before commencing with the cut.
- ⇒ All drilling swarf should be removed from the vehicle and all holes drilled in the vehicle should be treated with an appropriate rust inhibitor.
- ⇒ Do not fully tighten bolts before towbar is completely fitted unless instructed to do so in the fitting instruction, this will allow some variances to be overcome before final tightening of bolts.

PAINT & CORROSION

Towbars manufactured by PCT Automotive undergo a phosphate chemical pre-treatment prior to a finishing coat being applied. For long lasting good looks and in order to prevent corrosion the towbar should be regularly inspected for paint damage and wherever necessary re-painted in an appropriate finishing paint or underseal. The vehicle should also be regularly checked for any corrosion that could affect the towbar installation. Towbars should not be used on any vehicle suffering from corrosion that could affect the towbar installation.

BOLTS

All towbar fixing bolts should be checked initially after the first 300 towing miles, or the initial 500 miles of driving uncoupled, and then every 3,000 towing miles or to coincide with the vehicle manufacturer's recommended service intervals, whichever is the sooner. All towbar fixing bolts should be tightened using an appropriate torque wrench to the settings specified in the towbar fitting instruction.

ELECTRICAL INSTALLATION, TEST/COMMISSIONING AND MAINTENANCE

Failure to comply with the following instructions may cause damage to the towing vehicle's wiring loom and/or towing electrics installation.

Where displacement tap connectors e.g. Scotchlocks, are the preferred method of connection, always use the correct colour coded tap connector for the size of cable to which it is to be connected. All towing relays and modules manufactured by PCT Automotive have cabling with a copper cross-sectional area in the range 0.5mm² to 1mm².

After installation of the 12N/12S/13Pin sockets, prior to testing, a water displacement agent e.g. WD40 should be applied into the rear connection void through the water drain hole at the bottom of the sockets and also into the front pins under the socket flap. This socket maintenance should be carried out at least twice a year in the spring and autumn.

The towing electrics test procedure must be undertaken with the engine running. If any of the towing relays fail to function correctly, with the engine running and no other vehicle electrical systems turned on, check that the voltage across the vehicle's battery is between 13V and 14V approx, if this voltage is not correct, check the condition of the vehicle's battery/alternator.

Always ensure that the trailer/caravan/lighting board's own electrical systems are installed and functioning correctly before coupling to the vehicle's 12N/12S/13Pin sockets.

Every six months (spring and autumn recommended) the battery and alternator of the vehicle should be checked to determine correct electrical functioning. All connections of the electrical installation including the earth should be checked for mechanical soundness and electrical quality. Plugs, sockets, relays and fixings should be checked for water ingress, mechanical soundness, electrical quality and general wear and tear.

Please complete the following information to validate the guarantee and for future reference.

VEHICLE OWNER NAME & ADDRESS:

VEHICLE MAKE & MODEL:

VEHICLE REGISTRATION NUMBER:

FITTER NAME & ADDRESS:

DATE TOWBAR FITTED:

If you have any comments or suggestions about the PCT Automotive product fitted to your vehicle, please address them to PCT Automotive Limited, New Street, Holbrook Industrial Estate, Sheffield S20 3GH or email techsupport@pctautomotive.com
Your comments will help us in our aim to continually upgrade our products to meet the high standards expected by our customers.