

ZMMP9421 Up To 5.7m Motorhome Cover

Our breathable motorhome covers are made from heavy duty 4-ply non-woven polypropylene fabric which is UV stable and highly water resistant, giving excellent protection from the elements.

Benefits of Water Resistant Material

Water resistant means that the material will inhibit the transit of moisture to a given degree under testing using a known area of medium and barometric pressure. Water resistant (sometimes referred to as 'breathable') covers allow the transit of moisture after a certain amount of rainfall, and will more readily allow evaporation of both rainfall and naturally occurring condensation.

- Maypole's dark grey motorhome covers have additional features that are designed to improve the fit and functionality of the cover, including;
 - **Reflectors on the front and rear enhances night time visibility**
 - **Elasticated hem allows a tailored fit over a range of motorhome sizes**
 - **Nylon straps and plastic buckles on the side, front and rear to secure the cover when fitted**
 - **Extra strong double stitched seams on the straps to ensure product life**
 - **Zips on all 4 corners to aid fitting**
 - **Additional zips on both sides for easy door access**
 - **Handy storage bag for when not in use**
- Cover height 270.5cm
- Maypole logo on the front of the cover
- Non-abrasive material that prevents any scratches to your vehicle
- Easy to fit (fitting instructions included)
- Protect your motorhome when in Winter storage
- Protects from rain, snow, dust, tree sap, birds and leaves.
- UV stable
- MP9421 Up To 5.7m Motorhome Cover Dimensions:
 - **Length 572cm**
 - **Width 235cm**
 - **Height 270.5cm**
- Highly water resistant material (up to 1000mm hydrostatic pressure head test) providing excellent protection from the elements

PLEASE NOTE If your motorhome has a cab hump, we recommend you purchase a cover that is the next size up.

Breathable Motorhome Cover Fitting And Care Instructions Important : • Do NOT attempt to fit the cover in windy conditions. • Do NOT use your motorhome's heating system with the cover fitted. • Do NOT attempt to drive your motorhome with the cover fitted. • When opening and closing a zip, always ensure the cover surrounding it is straight. and not too tight. This will prevent excessive strain and possible failure of the zip. • Do NOT over-tension straps as this may damage your cover. • To help prevent the natural growth of mould inside the vehicle; regular ventilation and the use of a dehumidifier is recommended in long term storage. • During long term storage it is recommended the exterior of the vehicle is regularly cleaned to help minimize the possibility of mould growing between the body work and the cover. Before fitting your cover : • Remove, fold away or cover any sharp or fragile objects (such as aerials, guttering, wing mirrors, awnings and ladders etc) on the exterior of your motorhome to avoid damage to both them and the cover. • Close all windows and rooflights etc. • Ensure that fridges and heaters etc are turned off and the handbrake is applied. • It is preferable, but not essential, that your motorhome exterior is dry before fitting your cover. In order to prevent scratching, it MUST be clean and free of any loose particles or grit. Fitting your cover : Two people and the careful use of stepladders or a stable platform will be required as the cover is large, heavy and needs to be passed carefully over all sections of your motorhome. WARNING : If using stepladders or a platform you will be working at

height and should follow carefully the stepladder / platform manufacturer's safety instructions. You should not attempt to fit the cover from the ladder but only to use the ladder if required to assist people on the ground. 1. Open out the cover. The front section is clearly identified with a "FRONT" label. 2. Unzip the rear panel. 3. Starting from the front and working towards the rear, lift the cover carefully over the roof and all protruding objects. If necessary, unzip the front section also. 4. Adjust the cover's position until an even fit all over is achieved. 5. Close the zips carefully and fasten the Velcro tabs, as shown in the photo on the box. 6. Secure the sides of the cover with the straps provided. Pass each strap under your motorhome and secure to the corresponding buckle on the opposite side. 7. Adjust all straps as required to give a good fit, including those on the front and rear, as shown in the photo on the box. Care of your cover : • Allow the cover to dry completely before storing in the bag provided. • Do NOT machine wash or tumble dry this cover. Remove dirt with a soft sponge and warm water. Do NOT use detergent. • Do NOT expose this cover to sparks, flames or other sources of ignition.